


Connection diagram



Pressure gauge for 370Z.




Power cable
1 meter


Sensor cable
5 meters


OEM pressure sensor



Connect to the new pressure sensor







Make a hole in the pipe for the cables to pass through.




Connect the cables to the electronic board, passing through the bottom of the air vent.






Replace the air vent, taking care to position it correctly.

Installing the oil pressure sensor



Remove the OEM pressure sensor



Don't forget to seal all threads.

It's important to check for leaks before making any long journeys.

Be sure to check your oil level at the end of the installation.